


Safety switch

Series Safety Hinge Switch SHS

Description SHS-A1Z-SA

Article number 6019261015



BERNSTEIN AG . Hans-Bernstein-Straße 1 . 32457 Porta Westfalica . www.bernstein.eu

Technical Data



Electrical Data		
Rated insulation voltage	U,	250 V
Rated impulse withstand voltage	$U_{_{imp}}$	2,5 kV
Conv. thermal current	l ,	3 A
Rated operational voltage	Ue	230 V AC / 60 V DC
Utilization category		DC-13, 60 V DC / 0,5 A
Direct opening action	\bigcirc	acc. to IEC/EN 60947-5-1, annex K
Short-circuit protective device		Fuse 4 A gG
Protection class		SELV
Mechanical data		
Enclosure		GD-Zn
Cover		GD-Zn

Cover	GD-Zn
Wing	GD-Zn
Ambient air temperature	-25 °C to +70 °C
Contact type	1 Change-over
Mechanical life	1 x 10 ⁶ operating cycles
Switching frequency	max. 1200 switching operations / hour
Attachment	4 x M6 screws DIN 7984 or DIN 6912
Connection type	plug M12 x1, metal thread
Weight	$\approx 0.4 \text{ kg}$
Installation position	operator definable
Protection type	IP 67 in acc. with IEC/EN 60529
Switching angle	+/- 3 ° from fixing point
Direct opening angle	+/- 10 ° from fixing point
Direct opening torque	1,5 Nm
Mechanical load	F _{R1} = max. 1000 N
(see dimensioned drawing for the introduction direction of the forces)	F _{R2} = max. 500 N
	F _A = max. 750 N

ID for safety engineering	
B10d	2 x 10 ⁶ switching cycles
Standards	

VDE 0660 T100, DIN EN 60947-1, IEC 60947-1
VDE 0660 T200, DIN EN 60947-5-1, IEC 60947-5-1
DIN EN ISO 13849-1

EU Conformity

acc. to directive 2006/42/EC

Approvals

cCSA{US} C300

CCC

BERNSTEIN AG . Hans-Bernstein-Straße 1 . 32457 Porta Westfalica . www.bernstein.eu

Technical Data



Notes

The safety fixture must always be attached by at least two SHS! See max. load.

If the risk assessment of the machine permits a single-channel evaluation, an empty hinge can be used as the support element. If the SHS is used at an ambient temperature of 70 °C, it is possible that the connecting cable will age more rapidly!

The connecting cable must be protected against mechanical damage.

The cable can be installed in tubes or cable ducts.

The manufacturer / supplier of the machine / system is obligated to observe the applicable standards for the size of the safety intervals between the separating safety fixture and the hazard point.

These regulations include: EN 294, EN 349, EN 953, EN 1088,

The switch may not be used as a stop.

For a CSA/UL application it is essential to use CSA/UL approved cable for connection.

The suggested protection type (IP code), applies only when at least an equivalent cable coupling is used.

BERNSTEIN AG . Hans-Bernstein-Straße 1 . 32457 Porta Westfalica . www.bernstein.eu